

HONDA Shadow Sabre 1100 cc 1998-1999

PIECES INCLUSES	PARTS INCLUDED
1 Attache 1 Boule 1-7/8'' 1 Plaque de chaîne de sécurité 2 Tige aluminium 10'' cc (2 boulons 5/16x3/4'', 2 rondelles frein, 2 capuchons chrome 5/16)	1 Hitch 1 Ball 1-7/8'' 1 Safety chain plate 2 Aluminium hangers 10''cc (2 bolts 5/16x3/4'', 2 lock washers, 2 cap nut 5/16)

- 1- Remplacer la partie arrière du tube rond servant de support au tuyau d'échappement par l'attache. Récupérer les collets déjà en place pour l'installation.
- 2- La partie trouée inférieure se boulonne sous le support des tuyaux d'échappement.
- 3- Les bras d'aluminium se boulonnent au support de valises.

- 1- Replace rear round tubing by the hitch and save the clamps for installation.
- 2- Lower holed part bolt under muffler bracket.
- 3- Aluminum holders bolt on saddle-bag frame.



ATTENTION ! L'installateur a la responsabilité de s'assurer que tout, y compris les composantes préassemblées, soit bien serré avant d'utiliser la moto.

It is the installer's responsibility to ensure that all of the fasteners (including preassembled) are tightened before operation of the motorcycle.