



KAWASAKI Vulcan 1600 cc Classic 2003-2008
 KAWASAKI Vulcan 1600 cc Nomad 2005-2008

| PIECES INCLUSES | PARTS INCLUDED |
|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| 1 Attache zinc 1 Langue chrome 1 Boule 1-7/8" 1 Plaque de chaîne de sécurité 2 Boulons 1/2 x 1 1/4" 2 Rondelles freins 1/2 2 Boulon 5/16 x 1 3/4" allen 2 Boulon 5/16 x 3" 4 Écrous nylon 5/16 | 1 Zinc plated Hitch 1 Chrome receiver 1 Ball 1-7/8" 1 Safety chain plate 2 Bolt 1/2 x 1 1/4" 2 Lock washer 1/2 2 Allen bolt 5/16 x 1 3/4" 2 Bolt 5/16x 3" 4 Nylon nut 5/16 |

- 1- Soulever la moto pour obtenir l'espace requise pour l'installation. **TRÈS IMPORTANT**, vérifiez que l'espace entre l'aile et le pneu soit le même de chaque côté, et qu'il y ait assez d'espace pour l'attache - si l'aile n'est pas alignée avec le pneu, peut frotter sur l'attache.
- 2- Introduire l'attache sous l'aile, les points de fixation correspondent à ceux des supports de valises. Vous devrez soulever la rampe chromée de chaque côté de l'aile pour trouver les trous correspondants.
- 3- Des boulons plus longs sont fournis. Vous installerez **les boulons arrière de l'intérieur vers l'extérieur et les boulons avant de l'extérieur vers l'intérieur**. Défaire les filets existants pour insérer les boulons fournis.

- 1- *Lift the bike to get enough space between wheel and fender. **VERY IMPORTANT** : Make sure the space between the tire and the fender is the same on each side, be sure there is enough room for the hitch - a fender not aligned with the tire might cause hitch rubbing.*
- 2- *Install the hitch in the fender, pin points fit with the saddle bags support holes. You will take off the chrome struts to find the corresponding holes.*
- 3- *Longer bolts supplied. You will install **the bolts rear bolts from the inside to the outside and the front bolts from outside to the inside**. Drill the thread to insert bolts supplied.*

