



Harley-Davidson FLHRC 2009-2013  
 Harley-Davidson FLTR 2009  
 Harley-Davidson FLTRU 2011-2012  
 Harley-Davidson FLHTCUSE 2009-2013

PIECES INCLUSES	PARTS INCLUDED
1 Attache	1 Hitch
1 Langue chrome	1 Chrome receiver
1 Boule 1-7/8"	1 Ball 1-7/8"
1 Plaque de chaîne de sécurité	1 Safety chain plate
2 Boulons 1/2x1-1/4"	2 Bolts 1/2 x 1 1/4"
2 Rondelles frein 1/2	2 Lock washers 1/2
2 Plaques latérales noires (1 gauche, 1 droite)	2 Black side plates (1 left , 1 right)
6 Boulons 5/16 x 1"	6 Bolts 5/16 x1"
6 Écrous nylon 5/16	6 Lock Nuts 5/16
2 Boulons 1/4x1"	2 Bolts 1/4 x1"
2 Rondelles frein 1/4	2 Lock washers 1/4

- 1- Enlever les valises.
- 2- Desserrer les boulons de la moto qui serviront à l'installation de l'attache (voir photos).
- 3- Pour introduire les sections noires, serrer les boulons à la main :
  - a. Positionner le trou avant, entre la bande chromée et le support de valise.
  - b. Positionner le trou arrière, sous la bande chromée.
- 4- Attacher la section chromée à la section noire (section noire à l'extérieur).
- 5- Fixer la section du bas aux boulons de support d'échappement.
- 6- Serrer tous les boulons et réinstaller les valises.

- 1- *Remove the saddlebags.*
- 2- *Release bolts that will be required for the installation (see pictures).*
- 3- *Insert the black side plates;*
  - a. *front hole between chrome fender side cover and saddlebags support.*
  - b. *rear hole behind chrome fender side cover, tight the bolts by hand.*
- 4- *Attach the chrome section to the black bottom section (black goes outside).*
- 5- *Hold the lower section to the exhaust support bolts.*
- 6- *Tight all the bolts and put the saddlebags back on the bike.*

*Black saddlebags brackets need to be filed down and valve support to be cut.*  
 Les supports de valises doivent être “grindés” et le support de valve doit être coupé.

