



Harley-Davidson FLHX 2009-2013
 Harley-Davidson FLTRX 2010-2013
 Harley-Davidson FLTRSE 2009

PIECES INCLUSES		PARTS INCLUDED	
1	Attache	1	Hitch
1	Langue chrome	1	Chrome receiver
1	Boule 1-7/8"	1	Ball 1-7/8"
1	Plaque de chaîne de sécurité	1	Safety chain plate
2	Boulons 1/2x1-1/4"	2	Bolts 1/2 x 1 1/4"
2	Rondelles frein 1/2	2	Lock washers 1/2
2	Plaques latérales noires (1 gauche, 1 droite)	2	Black side plates (1 left , 1 right)
6	Boulons 5/16 x 1"	6	Bolts 5/16 x1"
6	Écrous nylon 5/16	6	Lock Nuts 5/16
2	Boulons 1/4x1"	2	Bolts 1/4 x1"
2	Rondelles frein 1/4	2	Lock washers 1/4

- 1- Enlever les valises.
- 2- Desserrer les boulons de la moto qui serviront à l'installation de l'attache (voir photos).
- 3- Pour introduire les sections noires, serrer les boulons à la main :
 - a. Positionner le trou avant, entre la bande chromée et le support de valise.
 - b. Positionner le trou arrière, sous la bande chromée.
- 4- Attacher la section chromée à la section noire (section noire à l'extérieur).
- 5- Fixer la section du bas aux boulons de support d'échappement.
- 6- Serrer tous les boulons et réinstaller les valises.

- 1- *Remove the saddlebags.*
- 2- *Release bolts that will be required for the installation (see pictures).*
- 3- *Insert the black side plates;*
 - a. *front hole between chrome fender side cover and saddlebags support.*
 - b. *rear hole behind chrome fender side cover, tight the bolts by hand.*
- 4- *Attach the chrome section to the black bottom section (black goes outside).*
- 5- *Hold the lower section to the exhaust support bolts.*
- 6- *Tight all the bolts and put the saddlebags back on the bike.*

Black saddlebags brackets need to be filed down and valve support to be cut.
 Les supports de valises doivent être “grindés” et le support de valve doit être coupé.

