

HONDA 1300 cc VT Interstate 2010 +

PIECES INCLUSES		PARTS INCLUDED	
1	Attache chrome	1	Hitch
2	Plaques latérales noires	2	Side plates black
1	Boule 1-7/8"	1	Ball 1-7/8"
1	Plaque de chaîne de sécurité	1	Safety chain plate
6	Boulons 5/16 x 1"	6	Bolts 5/16 x 1"
6	Écrous 5/16	6	Nuts 5/16
6	Rondelles frein 5/16	6	Lock washers 5/16

- 1- Enlever les valises.
- 2- Vous utiliserez les boulons d'origine pour fixer les plaques latérales noires.
- 3- Les boulons fournis serviront à fixer la pièce chrome aux plaques noires.

- 1- *Remove the saddle bags.*
- 2- *You will use OEM bolts to attach black side plates to the bike.*
- 3- *Bolts supplied will be required to join the chrome hitch and black plates together.*



ATTENTION ! L'installateur a la responsabilité de s'assurer que tout, y compris les composantes préassemblées, soit bien serré avant d'utiliser la moto.

It is the installer's responsibility to ensure that all of the fasteners (including preassembled) are tightened before operation of the motorcycle.