



BMW K1600GTL/GT 2011+

PIECES INCLUSES		PARTS INCLUDED	
1	Attache	1	Hitch
1	Boule 1-7/8''	1	Ball 1-7/8''
1	Plaque de chaîne de sécurité	1	Safety chain plate
4	Boulons M8 X 1.25 X 40 MM (tête allen)	4	Bolts M8 X 1.25 X 40 MM (allen head)
4	Écrous nylon m8	4	Lock nut m8
6	Boulons 5/16 x 1''	6	Bolts 5/16 x 1''
4	Rondelles 5/16	4	Washer 5/16
6	Écrou nylon 5/16	6	Lock nut 5/16
5	Pièces noir	5	Black components

1. Enlever les valises et le siège
2. Introduire les crochets sous le siège en les accrochant au tube du châssis (les glisser vers l'arrière). Boulonner en place et rejoindre, sous l'aile, les bras d'aluminium fournis.
3. Introduire l'attache de sorte à rejoindre les boulons des supports de mufflers.
4. Boulonner tous les points de fixation à l'attache et remettre les équipements au préalable enlevés.

- 1- *Take off the saddlebag and seat.*
- 2- *Put on the frame tubing, under the seat, hooks supplied. Bolt them on, and reach (under the fender) aluminium braces supplied.*
- 3- *Put on the hitch to reach the muffler support on frame.*
- 4- *Put everything back in place and tighten the bolts.*

**ATTENTION !** L'installateur a la responsabilité de s'assurer que tout, y compris les composantes préassemblées, soit bien serré avant d'utiliser la moto.  
*It is the installer's responsibility to ensure that all of the fasteners (including preassembled) are tightened before operation of the motorcycle.*

