



HARLEY-DAVIDSON FLD Switch Back

PIECES INCLUSES		PARTS INCLUDED	
1	Attache	1	Hitch
1	Langue Chrome	1	Chrome receiver
1	Boule 1-7/8"	1	Ball 1-7/8"
1	Plaque de chaîne de sécurité	1	Safety chain plate
2	Boulons 1/2 x 1-1/2"	2	Bolts 1/2 x 1-1/2"
2	Rondelle frein 1/2	2	Flat washer 1/2

1. Enlever les valises.
2. Dévisser la quincaillerie à l'endroit où l'attache sera fixé.
3. L'attache ne touche pas l'aile, placer par-dessus le couvert chrome.
4. Placer vis-à-vis les trous, retirer les 4 spacers chrome et réinstaller les boulons d'origine.
5. Remettre tout en place et resserrer les boulons.
6. Si la moto possède des équipements supplémentaires, il se peut que vous deviez changer la quincaillerie.

- 1- *Remove the saddlebags.*
- 2- *Take off the hardware where the hitch must be installed.*
- 3- *Hitch should not touch the fender, goes on the chrome side cover.*
- 4- *Put on the hitch according to the matching bolting points, remove the 4 oem spacers and bolt on with OEM bolts.*
- 5- *Put everything in place and tighten the bolts.*
- 6- *If the bike has extra equipment, you might have to get extra hardware to install it.*

ATTENTION ! L'installateur a la responsabilité de s'assurer que tout, y compris les composantes préassemblées, soit bien serré avant d'utiliser la moto.
It is the installer's responsibility to ensure that all of the fasteners (including preassembled) are tightened before operation of the motorcycle.

