

PIECES INCLUSES	PARTS INCLUDED
1 Attache 1 Langue Chrome 1 Boule 1-7/8'' 1 Plaque de chaîne de sécurité 6 Boulons M8 x 1.25 x 20mm 2 Écrous nylon M8 2 Tige aluminium (2 boulons 5/16x3/4'', 2 rondelles frein, 2 capuchons chrome 5/16)	1 Hitch 1 Chrome receiver 1 Ball 1-7/8'' 1 Safety chain plate 6 Bolts M8 x 1.25 x 20 mm 2 Nylon nut M8 2 Aluminium braces (2 bolts 5/16x3/4'', 2 lock washers , 2 cap nut 5/16)

1. Enlever les valises et/ou les 4 boulons des supports de mufflers arrière, boulons fournis.
2. Placer l'attache entre le muffler et le support de muffler, boulons fournis.
3. Voir sous l'aile les 4 boulons (2 de chaque côté) qui fixent l'arrière de l'aile au châssis. Enlever les 2 boulons en avant et poser les 2 tiges fournies en utilisant les mêmes boulons. Fixer au bas sur l'attache avec boulons fournis.

*Il est préférable d'utiliser un composé de retenu (locktite) pour un maximum de sécurité, ne pas trop serrer.

- 1- *Remove the saddlebags and/or the 4 bolts on rear mufflers support; bolts supplied.*
- 2- *Place the hitch between muffler and muffler support, bolts supplied.*
- 3- *Look at the 4 bolts (2 on each side) that hold the rear fender to the frame. Remove the 2 front bolts and put the hangers supplied using the oem bolts. Bolt the bottom of the hangers to the hitch, bolts supplied.*

*You must use locktite for a maximum of security. Do not over tight.

